

INSPECTION + INTERVENTION	1 x day	1 x week	x month	1/2 year	1 x year	PROBLEM / SOLUTION
CHECK OIL PRESSURE : 0,5 <-> 3 Bar	X		X	X	X	top it up as necessary
CONTROL OIL LEAKS	X		X	X	X	repair necessary
OIL LEVEL		X	X	X	X	level between indicators
CHANGE OIL + OILFILTER				X	X	MAX 500 hours( 1° service after10h)
WORKING PRESSURE - MAX PRESSURE	X		X	X	X	see manual - as type
STATE OF THE SUCTION FILTER	X		X	X	X	clean or replace as necessary
CHANGE OF SUCTION FILTER			X	X	X	
FAN + RADIATOR		X	X	X	X	clean or replace as necessary
CHECK MECHANICAL TRANSMISSION	X		X	X	X	re -tension or replace
ROTATING IN REVERSE WHEN UNLOADING	X		X	X	X	non-return valve problem
DISMANTLE NON-RETURN VALVE				X	X	clean or replace as necessary
COLLARS AND FITTINGS		X	X	X	X	re -tension or replace
AIR LEAKS	X		X	X	X	re -tension or replace
FUNCTION RELIEF SAFETY VALVE	X		X	X	X	replace if necessary
LUBRICATE COUPLING			X	X	X	
TIGHTENING BOLTS/ NUTS				X	X	
<b>WATCH OUT:</b> <ul style="list-style-type: none"> <li>- respect max speed range</li> <li>- check or work only when compressor is stopped and cold</li> <li>- at long stop : oil film on rotor necessary</li> <li>- check manual + only use prescribed oil</li> </ul>						





